



STRONG EUROPE

Together... Stronger!!!

abezeta
YOUR GLOBAL PARTNER

RC0012 – DELETION PEN POS

Deletion pen for analogue, thermal positive and high chemical resistance plates.

Properties

Its effective action in removing the coating does not damage the anodic layer, leaving unaltered the water acceptance properties.

How to use

- During plate preparation, apply DELETION PEN RC0012 over the area to be corrected.
- Leave to act for about 30 seconds and clean with plenty of water.
- Apply again the finishing gum.
- On press it is sufficient to wipe with a wet sponge to remove the remains of the fluid before resuming the print run.

Packaging

Dual point: Fine (F) and wide (G) point.

Application

Suitable for all types of analogues, thermal positive and high chemical resistance plates.

Considerations

- Apply the deletion pen on dry areas.
- If difficulties are observed in removing the coating, leave it to act for 15 seconds, remove the product with a cloth and reapply the deletion pen for another 15 seconds.
- On press, if the image area is covered by ink, remove the ink and dry the area well before applying the deletion pen.
- Store the deletion pen away from heat sources.